

Wall installation instructions

Flexible panels

SuperOrganic by Oberflex

For the following models :

Mur de fleurs
Champ d'été
Printemps
Pétales & Tournesols
Bleuets
Jardin de Roses
Alpage
Alpage & Bleuets
Alpage & Roses
Alpage et Pieds d'Alouette
Lavande
Epeautre
Paille de Noyer
Paille de Chêne

Receiving your order

Check that your shipment matches your order: models, sizes, quantities and condition of the goods. Linen models are supplied with an extra edge on each side and a width of 1.3 m. Therefore they need to be trimmed down before installation. The "Murs de fleurs" and "Champ d'été" models do not come with the extra edge.

If in doubt, please contact our customer service department before starting installation.

Storage

Store the panels away from moisture and dust, preferably flat.

Preparing the surfaces

Walls must be smooth, clean and dry. Plasterboard or other excessively absorbent surfaces must be primed before gluing the panels.

Preparing the panels

SuperOrganic panels are decorated in a natural and random pattern. Therefore, each panel should be visually checked prior to gluing to determine the order of installation.

For all models except "Murs de fleurs" and "Champ d'été", cut the two right and left side edges in parallel to bring the panels to a width of 1.3 m (standard width) as they often have fewer botanical patterns.

The panels are to be cut manually using a utility knife (ideally with a 30°), a cutting ruler, scissors for thick fabrics or a universal electric shears.



Gluing

We recommend using ready-to-use wallcovering adhesives with a high content of dry extracts. See glue recommendations on the back of this document.

Do a preliminary test to choose your glue and determine the amount to be used. Apply the adhesive to the wall with an applicator roller, following the manufacturer's instructions.

Use a flexible wallpaper spatula (e.g. Metylan) or a rubber roller, making sure not to crush the botanical pattern. The joints on the "edge to edge" or "double cut" panels must be carefully smoothed out using a foam roller.

Wipe off any excess glue immediately with a sponge moistened with warm water.

Wall installation instructions

Flexible panels

SuperOrganic by Oberflex

For the following models :

Mur de fleurs
Champ d'été
Printemps
Pétales & Tournesols
Bleuets
Jardin de Roses
Alpage
Alpage & Bleuets
Alpage & Roses
Alpage et Pieds d'Alouette
Lavande
Epeautre
Paille de Noyer
Paille de Chêne

Recommended glues

The choice of glue depends on the flexibility of the model to be applied and the nature of the support on which it will be applied; normally absorbent or non-absorbent.

A preliminary gluing test will make it possible to check the good resistance of the panel on the support and the absence of glue rising on the front of the decoration.

Models	Weight/m ²	Recommended glues	
		normally absorbent wall	non-absorbent wall
Printemps	< 400g	Ovalit TM (Henkel) Quelyd Murale (Bostik)	Ovalit Ultra (Henkel) Quelyd Optima 2 (Bostik)
Pétales & Tournesols			
Bleuets			
Jardin de Roses			
Alpage	> 400g	Ovalit S (Henkel) Ovalit F (Henkel) Quelyd Murale (Bostik)	Ovalit S (Henkel) Ovalit F (Henkel) Quelyd Optima 2 (Bostik)
Alpage & Bleuets			
Alpage & Roses			
Alpage et Pieds d'Alouette			
Lavande			
Epeautre			
Paille de Noyer			
Paille de Chêne			